



Rough Lift #A-2401

TECHNICAL INFORMATION

Step 1 Fold a flap on the end of the tape approximately 1/4". inch wide. (This will insure not leaving prints on the adhesive side of tape.) (see Fig 1 and 2).



Fig 1



Fig 2



Fig 3



Fig 4

Hold tape at folded tab use only enough tape to cover the latent print (**Fig 3**). For example if lifting single print only use a 2in. strip of Rough Lift tape. This tape does not tear like standard lifting tape, scissors will be required for cutting. (**Fig 4**)



Fig 5



Fig 6



Fig 7



Fig 8

Step 2 Hold the tape by the tab, place the tape on top of the latent print. (**Fig 5**). Using the index finger press firmly on the print, rubbing in a circular motion, forcing the Rough Lift Tape into the textured surface. (Do not try to press all the tape down only the area with the latent print.) (**Fig 6**)

Step 3 To lift the latent fingerprint; pull up on the tab. (**Fig 7**) The lift can now be placed on a backing card. (**Fig 8**) Note: If the Rough Lift tape is placed on a surface without the above recommended holding tab the clear backer will have the tendency to pull away from the adhesive. This can result in a non usable print.

ARROWHEAD FORENSICS

11030 Strang Line Road | Lenexa, Kansas 66215

PHONE 913.894.8388 FAX 913.894.8399

www.arrowheadforensics.com